

PT-12

Item ref: 174.248UK

Chromatic Pedal Tuner

User Manual




Caution: Please read this manual carefully before operating
Damage caused by misuse is not covered by the warranty

Thank you for choosing the Chord PT-12 pedal tuner for easy and accurate tuning of your instrument. Please read below for an explanation of the controls and to get the best results from your new effect.

The PT-12 is supplied with a 9V battery, which needs to be connected to the battery clip inside the underside battery compartment. Carefully remove the plastic cover by squeezing its clip and levering outwards. Clip back into place once the battery is fitted. Alternatively, the PT-12 can be powered from an external 9Vdc (centre-negative) power adaptor connected to the DC power in jack. Adjacent to this is a DC power out jack for daisy-chaining DC power onto other pedals.

Controls and connections are described below.



1. A4 frequency calibration button
2. Battery compartment
3. Output jack
4. Backlit LCD display
5. DC power out
6. DC power in
7. Tuner on/off foot switch
8. Input jack

The PT-12 pedal tuner is permanently set to chromatic tuning mode to detect any note between A0 and C8 (27.5 - 4186Hz). Press the foot switch to switch the tuner off or on. The tuner is only active when the display is lit, showing the detected note and a virtual needle. The output is muted when the tuner is active. When a note is in tune, the virtual needle will be in the centre of the screen and the backlight will change colour to green. Frequency for the A4 reference note should normally be 440Hz, but this can be calibrated between 430Hz and 450Hz using the rear push button if tuning to other instruments or tracks that are slightly out of standard tuning. Otherwise, ensure this is set to 440Hz.

Unplug the guitar input jack to preserve the battery when not in use. If the pedal is not being used for long periods, it is advised to remove the 9V battery. Optional external power can be from a 9Vdc adaptor, centre-negative polarity with a rating of 100mA or higher recommended.



Disposal: The "Crossed Wheelie Bin" symbol on the product means that the product is classed as Electrical or Electronic equipment and should not be disposed with other household or commercial waste at the end of its useful life. The goods must be disposed of according to your local council guidelines.

*Errors and omissions excepted. Copyright© 2023. AVSL Group Ltd.
Unit 2-4 Bridgewater Park, Taylor Rd. Manchester. M41 7JQ*

AVSL (EUROPE) Ltd, Unit 3D North Point House, North Point Business Park, New Mallow Road, Cork, Ireland